



Instruction manual DBF011

Winding the Movement

- Your watch is fitted with a manual-winding mechanical movement. For optimal performance, we recommend winding the movement each morning.
- Wind the movement by turning the crown clockwise until you feel resistance. Do not force the crown beyond this point.

Setting the Date

- Pull the crown out to Position 1. The date is set by advancing the hands.
- Turn the hands clockwise past midnight until the date advances by one day.
- Then turn the hands counterclockwise back to approximately 9 o'clock, and again turn them clockwise past midnight until the date advances once more.
- Repeat this procedure until the desired date is displayed.
- Once the correct date has been set, adjust the hands to the correct time.

Setting the Time

- After setting the date, move the hands to the current time.
- Be sure to distinguish between AM and PM, so that the date changes at midnight rather than at 12 noon.

Water Resistance

- Your watch has been tested at the factory for water resistance to 5 bar (5 ATM). This provides reliable protection against moisture encountered during normal daily wear.
- If the watch is worn regularly in water, we recommend having its water resistance checked once a year.
- To prevent water ingress, never operate or pull out the crown of the DBF011 while the watch is underwater.
- The leather strap is not designed for prolonged or repeated exposure to water. Frequent or extended contact with water may affect its appearance and reduce its service life.

Please handle your watch with the care it deserves.

If you have any questions, please feel free to contact us at info@duboisfils.swiss