

## Operating instructions DBF007 diver watch

### Unscrewing the crown

1. The DBF007 crown is screwed down to prevent water infiltration of the movement. To loosen the crown, carefully pull the crown out until it clicks.

Note: The watch is not waterproof when the crown is disengaged.

### Winding the watch

2. The crown is now in the correct position to be wound.
3. Wind the movement completely by turning it back and forth 40 times. Please do this whenever the movement has come to a standstill.

### Setting the time

4. Once the crown has been loosened (see point 1), gently rotate the crown to set the time.

### Setting the date

5. There is no quick date setting on this historical movement. If the date changes at 12 o'clock, turn the hand back to 9 o'clock, so 3 hours back and then again forward to 12 o'clock. Repeat the forward to 12, back to 9 process until the correct date is reached.

### Re-tightening the crown

6. Screw the crown snug by lightly pressing on the crown and at the same time carefully turning. Please do not screw the crown too much. It is enough to secure the crown with a light resistance to ensure waterproofness.

Questions? Please contact [info@duboisfils.swiss](mailto:info@duboisfils.swiss) at any time