



## Operating instructions DBF006 Bidynator

### Winding the movement

1. The crown is in the position where the movement can be wound.
2. Wind the movement completely by turning it back and forth 40 times. Please always do this when the movement has stopped.

### Setting the time

3. Pull the crown lightly to set the time.

### Setting the date

4. There is no quick date setting on this historical movement. If the date changes at 12 o'clock, turn the hand back to 9 o'clock, so 3 hours back and then again forward to 12 o'clock. Repeat the forward to 12, back to 9 process until the correct date is reached.

Questions? Please contact [info@duboisfils.swiss](mailto:info@duboisfils.swiss) at any time